

FIG. 1

Burst Length	Starting Column Address			Linear	Interleave
	A ₂	A ₁	A ₀		
2	V	V	0	0-1	0-1
	V	V	1	1-0	1-0
4	V	0	0	0-1-2-3	0-1-2-3
	V	0	1	1-2-3-0	1-0-3-2
	V	1	0	2-3-0-1	2-3-0-1
	V	1	1	3-0-1-2	3-2-1-0
8	0	0	0	0-1-2-3-4-5-6-7	0-1-2-3-4-5-6-7
	0	0	1	1-2-3-4-5-6-7-0	1-0-3-2-5-4-7-6
	0	1	0	2-3-4-5-6-7-0-1	2-3-0-1-6-7-4-5
	0	1	1	3-4-5-6-7-0-1-2	3-2-1-0-7-6-5-4
	1	0	0	4-5-6-7-0-1-2-3	4-5-6-7-0-1-2-3
	1	0	1	5-6-7-0-1-2-3-4	5-4-7-6-1-0-3-2
	1	1	0	6-7-0-1-2-3-4-5	6-7-4-5-2-3-0-1
	1	1	1	7-0-1-2-3-4-5-6	7-6-5-4-3-2-1-0

FIG. 2



FIG. 3

4/19




FIG. 4

08350719

5/19




FIG. 5

08 650719



08-350719

FIG. 8

FIG. 8

8/19




FIG. 9

9/19

001650719




FIG. 10

10/19

0000650719




FIG. 11

11/19

002650719




FIG. 12

12/19

003550719




FIG. 13

6170233800




FIG. 14

14/19




FIG. 15

000003507119

FIG. 16

16/19

00000650719




FIG. 17

FIG. 18




FIG. 19

BY	0.G. 110.	CLASS	RE-CLASS
CRAFTSMAN			

19/19

08/26/2019




FIG. 20